

Grandstream Networks, Inc.

GWN7302 PtP/PtMP

User Manual



Introduction

The **GWN7302** is an outdoor **PtP/PtMP Fixed Wireless Bridge** designed for **Point-to-Point (PtP)** and **Point-to-MultiPoint (PtMP)** deployments in business and infrastructure environments. It enables stable, long-distance wireless links up to **5 km** between remote locations with a clear line of sight.

Unlike traditional Wi-Fi access points, the GWN7302 is built for **transparent Layer-2 bridging**, allowing full extension of the local network across sites. It carries **DHCP, VLAN**, and **management traffic** just like an Ethernet cable.

With **5GHz directional antennas, 2x2:2 MIMO**, and **TDMA-based communication**, it helps reduce interference and maintain consistent performance. The **IP66-rated enclosure** makes it suitable for outdoor deployment in locations such as **construction sites, security camera poles, parking areas**, and **multi-building campuses**.

Deployment supports:

- **PtP Mode** – One Master connected to one Slave
- **PtMP Mode** – One Master connected to up to four Slaves

The setup process is streamlined using:

- **One-Key Pairing**
- **LED-based signal alignment**
- **Integrated Web UI, GWN App**, and **GDMS Cloud**

Note: *The GWN7302 is designed for infrastructure links and does not serve as a general Wi-Fi access point.*

This manual includes full guidance for installation, setup, pairing, alignment, and management.

Changes or modifications to these products not expressly approved by Grandstream, or operation of these products in any way other than as detailed by this User Manual, could void your manufacturer warranty.

Please do not use a different power adapter with these devices as it may cause damage to the products and void the manufacturer warranty.

Product Overview

Technical Specifications

Category	Specification
Wi-Fi Standards	IEEE 802.11 a/n/ac/ax
Antennas	2 single frequency antennas 5GHz x 2, gain 13.5dBi Beamwidth 5GHz: H:30°, V:30°
Wi-Fi Data Rates	5G: IEEE 802.11ax: 7.3 Mbps to 2402 Mbps IEEE 802.11ac: 6.5 Mbps to 1732 Mbps IEEE 802.11n: 6.5 Mbps to 300 Mbps IEEE 802.11a: 6, 9, 12, 18, 24, 36, 48, 54 Mbps <i>*Actual throughput may vary depending on many factors including environmental conditions, distance between devices, radio interference in the operating environment and mix of devices in the network</i>
Frequency Bands	5GHz Radio:5150 – 5895 MHz <i>*Not all frequency bands can be used in all regions.</i>
Channel Bandwidth	5G: 20, 40, 80, and 160 MHz (x2)
Wi-Fi and System Security	WPA2-PSK, WPA3-PSK, anti-hacking secure boot and critical data/control lockdown via digital signatures, unique security certificate and random default password per device


MIMO	2×2:2 5GHz
Coverage Range	Up to 5 kilometers <i>*Coverage range can vary based on environment</i>
Maximum TX Power	5G: 26dBm <i>*Maximum power varies by country, frequency band and MCS rate</i>
Receiver Sensitivity	5G: 802.11a: -92dBm@6Mbps, -74dBm@54Mbps; 802.11n 20MHz: -73dBm@MCS7; 802.11n 40MHz: -70dBm@MCS7; 802.11ac 20MHz: -67dBm@MCS9; 802.11ac 40MHz: -63dBm@MCS9; 802.11ac 80MHz: -59dBm@MCS9 802.11ax MIMO: -60dBm@MCS11; 802.11ax 40MHz: -58dBm@MCS11; 802.11ax 80MHz: -56dBm@MCS11; 802.11ax 160MHz: -52dBm@MCS11
Management SSID	Single 5G
Point to Multipoint	1 to 4
Network Interfaces	2 x 10/100/1000Mbps Ethernet
Auxiliary Ports	1x Reset and Pairing Pinhole
LEDs	1 tri-color LED for device tracking and status indication 3 x LED for signal strength 2 x LED for network port status
Network Protocols	IPv4, 802.1Q, 802.1p, 802.11e/WMM
QoS	802.11e/WMM, VLAN, TOS
Network Management	Embedded controller can manage via Web access GDMS Networking offers remote management via SSH tunneling GWN APP offers on-site management without LAN
Power and Green Energy Efficiency	DC: +24VDC (Compatible with 16VDC-48VDC), PoE/PoE+: 802.3af/at PSE output: max13W with PoE+ Input/max 25W with +24VDC/2A input
Environmental	Operation: -30°C to 60°C Storage: -30°C to 70°C Humidity: 5% to 95% Non-condensing
Physical	Unit Dimension: 180mm x 102mm x 38mm
Mounting	Wall mount or pole mount, kits included
Package Content	GWN7302 PtP/PtMP Fixed Wireless Bridge, Mounting Kits, Quick Start Guide
Weatherproof Grade	IP66-level weatherproof capability when installed vertically
Surge Protection	8KV
Compliance	FCC, CE, RCM, IC

GWN7302 Technical Specifications

Hardware Installation

Package Contents

The GWN7302 package includes the following components required for installation and setup:



Package Contents


Letter	Qty	Item Description
a	1	GWN7302 Device
b	1	Wall/Pole Bracket
c	1	Device Bracket
d	1	Steel Strap
e	1	Terminal Power Adapter (24V input)
f	4	Expansion Bolts
g	4	Screws (M4×8)
h	2	Screws (M3×8)
i	4	Screws (PA3.5×33)
j	1	Adhesive Sticker
k	1	Rubber Waterproof Accessory
L	1	Quick Installation Leaflet

Package Contents

Device Ports

The GWN7302 features:

- **NET1 Port** – PoE IN
- **NET2 Port** – PoE OUT
- **RST/PAIR Button** – for factory reset or one-key pairing
- **Power Terminal** – for 24V DC optional input



Port	Description
NET1 (PoE IN)	Ethernet RJ45 port (10/100/1000 Mbps) supporting PoE/PoE+ input. Use this port to power the device via a PoE injector or switch.
NET2 (PoE OUT)	Ethernet RJ45 port (10/100/1000 Mbps) with PoE/PoE+ output capability to power another PoE device (e.g., an IP camera or access point).
RST / PAIR	Multi-function button used to: • Press and hold for 7 seconds to reset to factory settings • Tap once for One-Key Pairing during PtP/PtMP configuration
Power Terminal (24V DC)	Power input via terminal block for 24V DC. Can be used if PoE is not available.

Ports

Device Mount

GWN7302 can be mounted on the wall or a metal bar. Please refer to the following steps for the appropriate installation.

Wall Mount

1. Attach the Device Bracket

Use the M3 screws to secure the device bracket to the back of the GWN7302.

2. Fix the Wall Bracket


Mount the wall/pole bracket to the wall using the expansion bolts and long screws..

3. Hook & Secure the Device

Align the device bracket with the mounted wall bracket, hook it into place, and secure it using the screws for firm attachment.

4. Tighten and Check

Ensure all screws are secure and the device is properly fixed and facing the correct direction.



Wall Mount

Pole Mount

1. Attach the Device Bracket

Use the M3 screws to secure the device bracket to the back of the GWN7302.

2. Fix the Pole Bracket


Insert the steel strap through the pole bracket and wrap it around the pole. Tighten the strap until the bracket is snug and level.

3. Hook & Secure the Device

Align the device bracket with the mounted pole bracket, hook it into place, and secure it with screws for a firm and stable attachment.

4. Final Check

Confirm the device is tightly mounted, facing the correct direction, and all fasteners are secure.



Pole Mount


Rubber Waterproof Plug Installation

The GWN7302 includes a **rubber waterproof plug** used to seal unused ports and maintain **IP66 protection** for outdoor use. Depending on your power method and port usage (NET1, NET2, DC IN), the plug can be configured in two ways:

Case 1: Using only NET1 (PoE IN)

If you're using only **NET1** for both power and data (typical for most PtP deployments):

- You **do not remove** any rubber inserts.
- You insert the **network cable (RJ45)** directly through the **main open port** on the rubber plug.
- The other two plug sections (NET2 + DC IN) **stay sealed**.




Case 1 Using only NET1 PoE IN

Case 2: Using NET2 and/or 24V DC Input

If you're using **NET2 (PoE OUT)** to power another device (e.g., camera) and/or supplying **power via the 24V terminal block**:

- You need to **remove the corresponding rubber seals** from the backside of the plug:
 - Remove the rubber cap for **NET2** if you're inserting a second Ethernet cable.
 - Remove the rubber cap for **DC IN** if using a 24V terminal adapter.
- Insert the cables through the newly opened holes.
- Then fit the rubber plug into the main unit as usual.



Case 2 Using NET2 and/or 24V DC Input

- Do not attempt to open, disassemble, or modify the device.
- Do not expose this device to temperatures outside the range of -30 °C to 60 °C for operating and -30 °C to 70 °C for storage.
- Do not expose the GWN7302 to environments outside of the following humidity range: 5-95% RH (non-condensing).
- Do not power cycle your GWN7302 access point during system boot-up or firmware upgrade. You may corrupt firmware images and cause the unit to malfunction.
- Please take lightning protection measures during installation (a lightning rod is required, and the device must be reliably grounded). It is recommended to use a surge protection device.

The GNU GPL license terms are incorporated into the device firmware and can be accessed via the Web user interface of the device at `my_device_ip/gpl_license`. It can also be accessed here: <https://www.grandstream.com/legal/open-source-software>

To obtain a CD with GPL source code information, please submit a written request to info@grandstream.com

Getting Started

Initial Access to the GWN7302

This section explains how to access the GWN7302 for the first time.


Pairing Guide (Recommended): Pairing is the most important step when deploying the GWN7302 in PtP or PtMP mode. This user manual provides a high-level overview only. For full step-by-step pairing instructions and best practices (including RST/PAIR button pairing), refer to the dedicated [GWN7302 Pairing Guide](#)

Option A: GWN App

When powered on, the GWN7302 broadcasts a Management Wi-Fi network for initial setup. The SSID is automatically generated and appears in the format: `GWN7302_XXXXXX` (where `XXXXXX` is the last characters from the device MAC address).


To access the device from a phone:

1. Connect your phone to the broadcast SSID (for example, `GWN7302_XXXXXX`).
2. Open the **GWN App** and select **Single Device**.




Login page

On the discovery page, tap **Connect to Wi-Fi** to search for the device. If the device is not detected, tap the ? icon to view connection guidance.



Login page

or select **Add with Device IP** to log in manually.



Login page

If you choose **Add with Device IP**, enter the device IP address and the device password (Web UI login password), then tap **Sign In**.

This method requires that your phone can reach the device IP on the same network.

10:42

< Add with Device IP

Please ensure the network connection between the mobile phone and the device is working properly

*Device IP

*Device Password

Please enter the web management password

Sign In

login page

For more details, check the [GWN7302 Pairing Guide](#)

Option B: MAC address or GWN Discovery Tool

Use this option when the GWN7302 and your computer are connected to the same local network (LAN), for example, connected to the same router or switch.


Method 1: Access using the device's local URL (MAC-based)

Locate the MAC address on the device label, then enter the following in a browser: ***https://gwn_MAC Address.local***

Example: If the MAC is *C0:74:AD:8C:4D:F8* , enter: *https://gwn_c074ad8c4df8.local*

Method 2: Access using the GWN Discovery Tool

Run the **GWN Discovery Tool**, click **Scan**, then use the discovered IP address to open the Web UI.




GWN Discovery Tool

Web UI Login

Log in using:

- **Username:** `admin`
- **Password:** the default random password printed on the device label (*unless previously changed*).



Login page

- Make sure the device is not already **paired to another master** or controller. If so, unpair or factory reset it first.
- It is the customer's responsibility to ensure compliance with local regulations for frequency bands, transmit power, and others.
- To manage remotely, use the **GDMS platform**: <https://www.gdms.cloud>.

For more details, check the [GWN7302 Pairing Guide](#)

LED Indicators


The LED indicators on the GWN7302 provide at-a-glance feedback for device status, pairing progress, network connectivity, and link quality. These indicators are especially useful during installation, antenna alignment, and troubleshooting.

LED	Status	Meaning
Sys (System)	Solid Yellow	Disconnected after pairing (Slave).
	Solid Pink	Device powered on & ready (factory default Slave mode or Pairing in progress).
	Blinking Pink	Discovering the device and establishing a connection.
	Rapidly Blinking Pink	Pairing confirmed (the RST/PAIR button was successfully pressed on the Slave device).
	Solid Blue	Paired successfully, link established.
	Solid Red	Pairing failed.
	Blinking Blue	Configuration update in progress
	Blinking green	Firmware update in progress
	Solid green	The firmware update successful/rebooting
	Blinking Red	Restore factory
Signal LEDs (3 bars)	1–3 Green bars	Slave: Link quality between this device and the paired Master. 3 LEDs turn blinking green in cycle when waiting to be discovered by Master.
		Master: All 3 LEDs turn solid green when role is active. 3 LEDs turn blinking green in cycle when scanning Slaves.
NET1 (PoE IN)	Solid/Flashing Green	Ethernet link or data activity (PoE input).
NET2 (PoE OUT)	Solid/Flashing Green	Ethernet link or data activity (PoE output).

Rebooting or Logging Out

The **Reboot** and **Logout** options are located in the **top-right corner** of the web interface under the **admin** menu.


- **Reboot:** Click **Reboot** to restart the device. This will briefly interrupt the wireless bridge and any connected devices.
- **Logout:** Click on **Logout** to securely exit the web interface. You will need to log in again to access the settings.



Rebooting or Logging Out

Search

The GWN7302 Web UI includes a built-in **Search Bar** for quick navigation. It's located in the **top-right corner** of the interface, next to the admin profile.



Search

How to Use:

1. Click the **magnifying glass icon**.
2. Type a keyword (e.g., "mode", "SSID", "IP", etc.).
3. Matching settings and menu items will appear instantly.

This feature helps you jump directly to RF settings, network services, or any advanced option without browsing through each tab manually.

Setup Wizard

The **Setup Wizard** is a built-in configuration flow that simplifies the initial setup of the GWN7302 for both **PtP** and **PtMP** deployments. It's ideal for first-time installation or post-reset reconfiguration.

The wizard appears automatically:

- On first login to a factory-reset device
- After manually selecting "**Setup Wizard**" from the **admin menu** in the top-right corner of the Web UI

The wizard can be re-run at any time without resetting the device.

Configuration Flow

The wizard consists of **three main steps**:

1. Basic Settings

- Select **Device Role**:
 - **Master**: Transmits the bridge signal and typically connects to the uplink network, such as a switch or router.
 - **Slave**: Receives the bridge signal and extends the network to a remote site, typically connecting to terminal devices such as cameras.
- Set **Country** and **Time Zone**

The screenshot shows the 'Setup Wizard' interface with three tabs: 'Basic Settings' (active), 'RF Settings', and 'Network Settings'. The 'Basic Settings' tab is highlighted with a red box and a blue circle with the number 1. The 'Role' section has 'Master' selected with a radio button, also highlighted with a red box. Below it, a warning message states: 'Modifying the role will clear the device pairing information and requires re-pairing.' The 'Country/Region' dropdown is set to 'Morocco' and the 'Time Zone' dropdown is set to 'UTC'. There is an 'Exit' button at the bottom left and a blue arrow button at the bottom right.

Setup Wizard Basic Settings

2. RF Settings

- Choose **Connection Mode**:
 - *PtP* (one Slave)
 - *PtMP* (up to 4 Slaves)
- Configure:
 - **SSID & Password**
 - **Channel Bandwidth** (20/40/80 MHz)
 - **TX Power** (Auto or Manual)

The screenshot shows the 'Setup Wizard' interface with three tabs: 'Basic Settings', 'RF Settings' (active), and 'Network Settings'. The 'RF Settings' tab is highlighted with a blue circle with the number 2. A tooltip explains: 'PTP mode can only pair 1 device, PTMP mode can pair with up to 4 devices. When more than one device has been paired, switching from PTMP to PTP mode is not supported.' The 'Connection Mode' section has 'PTP' selected with a radio button. The 'SSID' section has 'Primary Device SSID' entered in the text field. The 'SSID Password' section has a masked password. The 'Channel Bandwidth (MHz)' dropdown is set to '80', the 'Frequency' dropdown is set to 'Auto', and the 'TX Power (dBm)' dropdown is set to 'Auto'. There is an 'Exit' button at the bottom left and a blue arrow button at the bottom right.

3. Network Settings

- Choose IP mode: **DHCP** (default) or **Static**
- If Static: Enter
 - IP Address
 - Subnet Mask
 - Gateway
 - DNS Servers

Setup Wizard Network Settings

For more details, including full pairing steps and RF tuning, visit the official guide: [GWN7302 Pairing Guide](#)

Overview

Overview page

The **Overview** page provides a central dashboard for checking the current status of the GWN7302, including device information, bridge link status, alerts, and monitoring charts.

Topology and Link Status

The topology area shows the relationship between the current device and the paired device. It displays the device role, MAC address, IP address, link status, signal strength, throughput, and negotiated rate.


The device status indicator shows whether the paired device is online or offline:

- A green indicator means the device is online.
- A gray indicator means the device is offline.


When the paired device is online, the topology diagram displays real-time link information, including RSSI, upload/download throughput, and negotiated rate.

When the paired device is offline, the topology diagram shows the paired device with an offline status indicator and does not display active link statistics.

Click **Pair devices** to open the paired devices section and manage the device pairing.



Overview page



Overview page Device offline

Device Info

The **Device Info** panel displays basic information about the current GWN7302 device, including:

- Device Name
- MAC Address
- Hardware Version
- Firmware Version
- Serial Number
- Up Time
- System Time
- Security Version Number

Alerts

The **Alerts** panel displays recent system alerts with the alert content, severity level, and time. Click the arrow icon to view more alert details.

Monitoring


The monitoring area provides real-time and historical charts for the wireless bridge link.

Real-time Monitoring

The **Real-time Monitoring** tab displays live monitoring charts for the bridge link. The charts include:

- **Throughput:** Displays current traffic throughput.
- **Negotiated Rate:** Displays the current negotiated wireless rate.
- **Signal Strength:** Displays the current signal strength in dBm.

Each chart uses a short sampling duration and can be refreshed from the refresh icon.




Overview page Real time Monitoring

Historical Monitoring

The **Historical Monitoring** tab displays historical data for the bridge link. Use the available time range buttons, such as **2 hours**, **1 day**, or **1 week**, to review previous performance data.

The historical charts include:

- **Throughput**
- **Negotiated Rate**
- **Signal Strength**



Overview page Historical Monitoring

Network Status

The **Network Status** page displays real-time connection and link quality information for the GWN7302 device. This view is crucial for verifying physical port status, RF link parameters, IP addressing, and monitoring overall traffic flow.

Network Status

Network Info

Ethernet Port

Port Name	Connection Status	Port Speed	Port Mode	Flow Control
NET1(PoE IN)	Connected	1000 Mbps	Full	Off
NET2(PoE OUT)	Disconnected	--	--	--

Device IP

IP Address:	192.168.6.179	Preferred DNS:	192.168.6.1
Subnet Mask:	255.255.255.0	Alternate DNS:	8.8.8.8
Gateway:	192.168.6.1		

Port Statistics

Clear

Interface	MAC Address	Tx Bytes	Rx Bytes	Tx Packets	Rx Packets
Wired Network					
NET1(PoE IN)	EC:74:D7:81:4E:00	14483711	19200833	49864	109924
NET2(PoE OUT)	EC:74:D7:81:4E:00	0	0	0	0
Wireless Network					
ATH0	EC:74:D7:81:4E:00	4386403	4573615	56123	58187

RF Info

SSID:	GWN7302	Tx Rate:	6 Mbps
Role:	Master(PTP)	Rx Rate:	1201 Mbps
Channel Bandwidth:	80 MHz	RSSI:	-22 dBm
Tx Power:	23 dBm	SSID Status:	Connected
Channel:	CH48-5.24GHz		

Network Status

Ethernet Port Info

Displays the state of the two physical Ethernet ports:

Field	Description
PoE IN	Main power and data input port (NET1). Should show Connected with 1000 Mbps .
PoE OUT	Optional PoE passthrough port (NET2) for powering devices like cameras.
Port Mode	Displays duplex mode (typically Full).
Flow Control	Shows whether flow control is active.

Note: ➤ Clicking the **arrow icon** redirects to the **Network Settings** page for editing.

Device IP Info

Displays the current IP and DNS configuration of the unit:

- **IP Address**
- **Subnet Mask**
- **Gateway**
- **Preferred / Alternate DNS**

Note: Typically, these are assigned via DHCP unless a static IP was configured manually.

RF Info Summary

Shows key wireless parameters for the active PtP/PtMP link:

Field	Description
SSID	The used secure SSID for bridge communication (not broadcast to clients).
Role	Displays the device role: Master (PtP) or Slave
Channel Bandwidth	e.g., 80 MHz
TX/RX Rate	Real-time link throughput
RSSI	Received signal strength indicator (e.g., -16 dBm)
TX Power	Configured transmission strength
SSID Status	The secure SSID for bridge communication (not broadcast to clients).
Frequency	Current operating frequency (e.g., CH100-5.5GHz(DFS))

Notes:

- ➤ Clicking the **arrow icon** redirects to the **RF Settings** page.
- Clicking the **copy icon** next to SSID copies the SSID to the clipboard for quick reference.

Port Statistics

Live statistics for wired and wireless interfaces:


Metric	Description
Interface	Interface name (for example, NET1, NET2, Ath0).
MAC Address	MAC address of the selected interface.
TX Bytes / RX Bytes	Total transmitted/received bytes.
TX Packets / RX Packets	Total transmitted/received packets.

Note: Click the “Clear” button to reset all statistics counters.

Device Pairing

From the Master device:

1. Navigate to **Device Pairing**.
2. Click the **Add** button to start pairing.




Device Pairing								Pairing Guide
MAC Address	Device Name	IP Address	Rssi(dBm)	SNR(dB)	TX Rate(Mbps)	RX Rate(Mbps)	TX E	Action
EC:74:D7:7F:2E:2A	GWN7302	192.168.6.165	-44	53	6	864	154	

Device Pairing page on the master device

The **Pairing Guide** button opens the full GWN7302 Pairing Guide, which provides detailed pairing methods, preparation steps, and application scenarios.

Discovery – Finding Slave Devices

After clicking **Add**, the **Device Pairing → Preparations** page appears.



Device Pairing → Preparations

This page helps prepare both devices before discovery starts. Make sure all devices are powered on and wait for initialization to complete. Use the LED indicator reference to confirm the status of the **Current Device** and the **Device to be paired**.

Under **Select the pairing method**, choose one of the following:

Wired Pairing: Connect this device and the device to be paired to the same LAN using network cables. This method is recommended for more efficient pairing.

Wireless Pairing: Use this option when pairing wirelessly. Keep this device and the device to be paired more than 1 meter apart.

Click **Go to Pair** under the selected method to open the **Add Paired Devices** window.

After clicking **Go to Pair**, the **Add Paired Devices** window starts scanning for nearby Slave devices.



Master searching for slave devices


The Master displays “**Discovering pairable Slave devices...**” with a countdown while it searches (only for wireless pairing). Make sure the Slave device is powered on.

When devices are found, they appear in the **Add Paired Devices** window. The window includes two tabs: **Pairable** and **Manageable**.

If the list is still updating, wait for discovery to finish or click **Rediscovery** to scan again (only for wireless pairing).


Device List – Pairable & Manageable

After the scan, you’ll see a list of discovered devices:




When a slave device is found

Use the **Pairable** tab for a Slave device that is free, reset, or not already paired. Select the device checkbox, then click **Add**.




When a slave device is found Pairable

Use the **Manageable** tab when the Slave device is already paired and needs to be added to this Master. Select the device, then click **Add**.



When a slave device is found Manageable

In the **Manageable Device** window, enter the Slave device's **Web Login Password**, then click **OK** to allow this Master to take over the selected Slave.




When a slave device is found Manageable

Confirm & Complete Pairing

After clicking **Add**, the confirmation behavior depends on the selected pairing method.

For **Wireless Pairing**, the **Add Paired Devices** window starts a 30-second countdown and displays a message asking you to press the Slave device **RST/PAIR** button once within the countdown. Press the **RST/PAIR** button on the Slave device once to confirm pairing.




When a slave device is found

For **Wired Pairing**, no **RST/PAIR** button confirmation is required. After clicking **Add**, the device proceeds directly to pairing completion.


Successful Pairing or Failed Pairing

After pairing is completed, the device status changes to **Paired successfully**. The Slave may take a short time to initialize its configuration and go online.



The slave device has been successfully paired

If failed: Status will show **Failed to pair**.



Failed Pairing

At this point, the wireless link between the Master and the Slave is active. To add more Slaves, repeat the same sequence: **Add** → **discover** → **press the button on the Slave** → **check for “Paired successfully.”**

If pairing fails, the status will show **“Failed to pair”**. In this case, reset the Slave again (hold **RST/PAIR** for 7 seconds), make sure it is **powered on**, **within wireless range of the Master**, and **not already paired**, then repeat the pairing process from Step 1.

If pressing the **RST/PAIR** button on the Slave is not possible (e.g., the device is mounted or hard to reach), you can log in to the Slave manually via its web UI.

Set the **RF Settings** (Role = Slave, Mode = PTP or PTMP, SSID & Password) to match the Master.

Once saved, the device will automatically pair when the Master performs Step 1 and Step 2. No need to execute Step 3.

For more detailed pairing instructions, pairing methods, and deployment scenarios, refer to the [GWN7302 Pairing Guide](#)


Monitoring & Actions – After Pairing

Once paired:

- You’ll see the device listed with real-time stats such as **RSSI**, **SNR**, **Tx/Rx rate**, etc.
- You can click:
 - **Delete icon** to unpair the device (this triggers a reset).
 - **Diagnostic icon** to view the traffic statistics and graphs.
 - **Login icon** to directly access the Web UI of the paired device via its IP address.

Device Pairing								
Add		Pairing Guide						
MAC Address	Device Name	IP Address	Rssi(dBm)	SNR(dB)	TX Rate(Mbps)	RX Rate(Mbps)	TX Rate(Mbps)	Action
EC:74:D7:...	GWN7302	192.168.6.165	-44	53	6	864	154	Edit Diagnostic Delete

Monitoring Actions After Pairing



Monitoring

RF Settings

The **RF Settings** page is where users configure the wireless bridge parameters that define how the GWN7302 establishes the PtP or PtMP link. This section differs slightly depending on whether the device is acting as a **Master (Controller)** or a **Slave (Client)**.

For a complete explanation of pairing steps, setup wizard options, and RF behavior, refer to the full pairing guide: [GWN7302 Pairing Guide](#)

On the Master Device

The Master unit defines the wireless configuration that the Slave(s) will connect to. Key fields include:

These settings must be configured **before** pairing Slave devices.

RF Settings

Basic Wi-Fi Settings

Paired devices must be in the same SSID, password, and encryption method to prevent disconnection.

Connection Mode: ☐ PTP ☒ PTMP

*SSID: GWNDDDA40 (1-32 characters)

*SSID Password: (8-63 ASCII characters or 8-64 hexadecimal characters)

SSID Encryption: ☒ WPA2-PSK ☐ WPA3-PSK

Radio

TDMA: ☒

TDMA Work Mode: ☒ Static ☐ Dynamic

Channel Bandwidth (MHz): 80

Channel: Auto

TX Power (dBm): Auto

CCA Threshold: Custom

*Custom CCA Threshold (dBm): -59 (Range -94--11)

RS Settings On the Master Device

Field	Description
Connection Mode	Select how the Master connects: PTP (one Slave) or PTMP (up to 4 Slaves).
SSID	Wireless link name broadcast by the Master. Range: 1–32 characters.
SSID Password	Wireless link password used by the Slave(s). Range: 8–63 ASCII characters or 8–64 hexadecimal characters.
SSID Encryption	Select the encryption method for the wireless link (e.g., WPA2-PSK or WPA3-PSK).

	Note: WPA3-PSK will affect pairing. Please configure the Slave with the same SSID name, password, and encryption method as the Master, and then proceed with pairing once the SSID is connected.
TDMA	Enables TDMA to improve wireless link stability, especially for PTMP deployments or when the signal strength is below -55 dBm.
TDMA Work Mode (PTMP only)	Available when TDMA is enabled in PTMP mode. Static allocates time slots to all devices. Dynamic allocates time slots only to devices with data transmission. Use Static when a Slave cannot send enough data due to interference or long distance.
Channel Bandwidth (MHz)	Sets the channel width used by the wireless link. Wider bandwidth may increase throughput but can be more sensitive to interference.
Channel	Select Auto or a specific channel manually. Note: DFS channels may trigger radar detection behavior and may delay transmission or display prompts depending on regulatory requirements.
TX Power (dBm)	Sets transmit power (Auto or manual). Configure according to coverage needs and local regulatory limits.
CCA Threshold	Sets how the device determines if the channel is busy (Clear Channel Assessment). Usually left at default unless troubleshooting interference.
Custom CCA Threshold (dBm)	Manual CCA threshold value when CCA Threshold is set to Custom. Range shown in UI: -94 to -11 dBm.

RS Settings On the Master Device

On the Slave Device

The Slave unit needs to connect to the SSID defined by the Master. The page provides two methods:

- **Manual Entry:** Type in the SSID and password directly.
- **Scan + Select:** Click the **Scan icon** to discover nearby Slave devices. Then select the correct SSID and enter the password.

RF Settings

Basic Wi-Fi Settings

*SSID

🔍

*SSID Password

🔍

8-63 ASCII characters or 8-64 hexadecimal characters

SSID Encryption

☒ WPA2-PSK
☐ WPA3-PSK

Radio

TX Power (dBm)

▼

CCA Threshold ⓘ

▼


*Custom CCA Threshold (dBm)

Range -94--11

Cancel

Save

RS Settings On the Slave Device



Monitoring

Note: The link SSID is encrypted and only used for communication between GWN7302 units.

Network Settings

The **Network Settings** page on the GWN7302 controls how the device connects to the local network and passes data through its Ethernet ports. These settings apply to **both Master and Slave units**, and are critical for proper operation in PtP/PtMP mode.

Navigate to **Web UI → Network Settings**:

Port Name	Port Speed	Port Mode	Flow Control	Force Power Supply
NET1(PoE IN)	Auto			
NET2(PoE OUT)	Auto			

Network Settings page

Basic LAN Settings

Field	Description
IP Protocol	Choose between DHCP (default) or Static . Static IP is recommended in large networks to avoid IP conflicts or for static routing.
IP/Subnet/Gateway/DNS	Required only when Static is selected. These fields must be filled to ensure proper connectivity.
Management VLAN	Enables VLAN tagging for management traffic. Paired devices must be in the same management VLAN to prevent disconnection. When Allow is selected, you must also define a valid VLAN ID (1–4094).

Field	Description
VLAN ID	VLAN tag used for management access. Default is 2 . Must match your switch/router configuration.

Tip: VLAN support is useful when deploying the GWN7302 in segmented enterprise networks or when isolating management traffic.

Ethernet Port Configuration

Each port can be fine-tuned independently:

Field	Description
Port Name	NET1 = PoE IN, NET2 = PoE OUT
Port Speed	Options: Auto , 10Mbps, 100Mbps, or 1000Mbps (default).
Port Mode	Full or Half Duplex . Full is recommended for all deployments.
Flow Control	Enables Ethernet flow control for congestion prevention. Disabled when Half Duplex is selected.
Force Power Supply	Controls PoE OUT (NET2) forced power output. • Disabled: PoE OUT supplies power only when the input power is DC or 802.3at. • Enabled: PoE OUT is forced to supply power; when the input power is 802.3af, PoE OUT power may be unstable due to the input power limit.

Note: “When half-duplex mode is selected, traffic control does not take effect.”

Advanced

Field	Description
STP	Enables or disables Spanning Tree Protocol. STP helps prevent network loops when the device is connected to a switching network.

Once you’ve set the desired options, click **Save** at the bottom of the page.

Note: IP changes (especially switching from DHCP to Static) may cause a brief connectivity interruption.

Network Service

The **Network Service** section provides advanced management features for handling protocols and services such as multicast control, DDNS, SNMP, and remote provisioning.

Navigate to **Web UI** → **Network Service**:

Traffic Suppression

This page helps limit unwanted broadcast/multicast traffic from overwhelming the device or the wireless link. Enabling suppression can help maintain stable PtP/PtMP performance, especially in large Layer 2 networks.

Traffic Suppression

ⓘ

When the traffic exceeds the configured threshold, the device will discard the excess traffic to prevent data flooding.

Multicast/Broadcast Traffic Suppression

☒

*Suppress traffic (Kbps)

1000

Range 100-1000000

Cancel

Save

Network Service → Traffic Suppression

Option	Description
Multicast/Broadcast Traffic Suppression	Toggle ON to enable suppression. When enabled, excess broadcast or multicast traffic will be discarded once it exceeds the configured threshold.
Suppress traffic (Kbps)	Set the maximum allowed rate (in Kbps). Any traffic beyond this limit is dropped. Range: 100 – 1,000,000 Kbps

Warning Message: "When the traffic exceeds the configured threshold, the device will discard the excess traffic to prevent data flooding."

Tip: This is useful when connecting the GWN7302 to networks with chatty devices or unmanaged switches that send unnecessary broadcast floods (e.g., IPTV, unmanaged camera systems).

DDNS

The **DDNS** page allows the GWN7302 to dynamically update a hostname record with its current IP address. This is essential for remote management over the internet when the WAN IP is dynamic (DHCP).

DDNS

Enable DDNS

☒

Service Provider

Oray

Please go to www.oray.com and register to obtain the username, password and domain name.

*Username

*Password

*Domain Name

IP Source

☒ Device IP
 ☐ Public IP

Cancel

Save

Network Service → Traffic Suppression

Field	Description
Enable DDNS	Toggles DDNS functionality. Must be enabled to configure the options below.
Service Provider	Select from supported DDNS providers: Oray , Dyndns , or No IP .
Username / Password / Domain Name	Your DDNS account credentials and domain to link with the device.
IP Source	Choose whether the DDNS provider receives the device's internal IP (Device IP) or its external/WAN IP (Public IP) .

Tip: Use **Public IP** for remote access scenarios (e.g., accessing the GWN7302 from the internet). Use **Device IP** only in VPN or internal deployments.

SNMP

The **SNMP (Simple Network Management Protocol)** page allows external network management systems to monitor and configure the GWN7302.

Supports both **SNMPv1/v2c** (community-based) and **SNMPv3** (secure, user-based).

SNMP

SNMPv1,SNMPv2c

☒

*Community Name

public

1-32 characters

SNMPv3

☒

*Username

GWN7302

1-32 characters

Authentication Mode

☒ SHA ☐ MD5

*Authentication Password

8-32 characters

Privacy Mode

☒ AES128 ☐ DES

*Privacy Password

8-32 characters

Cancel

Save

Network Service → SNMP

Field	Description
SNMPv1, SNMPv2c	Toggle to enable legacy SNMP versions.
Community Name	Acts like a password for SNMPv1/v2c queries. Default is <code>public</code> . Allowed length: 1–32 characters .
SNMPv3	Toggle to enable SNMPv3, which uses secure user-based access.
Username	SNMPv3 login username. Max 32 characters.
Authentication Mode	Choose SHA (recommended) or MD5 .
Authentication Password	Password used with the selected authentication mode. Required, 8–32 characters .
Privacy Mode	Choose data encryption method: AES128 (recommended) or DES .
Privacy Password	Password for encrypting SNMPv3 payloads. Must be 8–32 characters .

Network Service → SNMP

Tip: *SNMPv3 is recommended for production deployments where secure communication is essential. SNMPv1/v2c may be used in simpler or legacy setups, but offer no encryption or strong authentication.*

Note: *If both SNMPv3 and v1/v2c are enabled, make sure the credentials used match what your external monitoring tool (e.g., Zabbix, PRTG, Nagios) supports.*

TR069

TR-069 (CWMP) enables remote management and provisioning of the GWN7302 via an **Auto Configuration Server (ACS)**. This is commonly used by service providers for large-scale deployments, monitoring, and firmware upgrades.

TR069

Enable TR-069

☒

*ACS Source ⓘ

ACS Username ⓘ

ACS Password ⓘ

Enable Periodic Inform

☒

If enabled, CPE will send connection inform packets to ACS periodically.

Periodic Inform Interval(s)

86400

86400 by default

ACS Connection Request Username ⓘ

ACS Connection Request Password ⓘ

ACS Connection Request Port ⓘ

7547

7547 by default, valid range is 1-65535

CPE Cert File ⓘ

CPE Cert Key ⓘ

Cancel

Save

Network Service → TR069

Field	Description
Enable TR-069	Frequency of inform packets (in seconds). The default is 86400 (i.e., once per day).
ACS Source *	URL or IP address of the Auto Configuration Server (ACS). Required.
ACS Username / Password	Credentials used by the device to authenticate with the ACS server.
Enable Periodic Inform	If enabled, the device will send inform packets to the ACS at regular intervals.
Periodic Inform Interval(s)	Port for inbound ACS requests. The default is 7547 , valid range: 1–65535 .
ACS Connection Request Username / Password	Credentials the ACS uses to remotely trigger a session on the device.
ACS Connection Request Port	Port for inbound ACS requests. Default is 7547 , valid range: 1–65535 .
CPE Cert File / Cert Key	Upload client-side certificate files if mutual TLS authentication is required by the ACS.

Tip: You must configure proper DNS, IP, and NAT/port forwarding on your router/firewall if using TR-069 across different networks or WAN interfaces.

Security Note: TR-069 introduces external control over the device, ensures strong credentials, enables TLS if supported, and locks ports when not in use.

System Settings

The **System Settings** section allows administrators to configure fundamental parameters related to the device's operation, access control, maintenance, and system alerts. This includes defining the device name and regional settings, applying firmware updates, managing administrator accounts, scheduling maintenance tasks, and enabling alert notifications. These configurations ensure secure access, consistent time synchronization, and optimal long-term performance of the GWN7302 in various deployment environments.

Basic Settings

This section contains **two tabs** for core configuration and GWN Manager integration:

Basic Settings Tab

Used to configure the device’s identity, location/time details, and PtP/PtMP role.

Basic Settings

Basic SettingsManager Server Settings

Device Name

GWN7302

1-64 characters

Country/Region ⓘ

Morocco

▼

Time Zone

UTC

▼

*NTP Server

pool.ntp.org

+

+

Role ⓘ

☒ Master

☐ Slave

ⓘ

Modifying the role will clear the device pairing information and requires re-pairing.

Cancel

Save

Network Settings → Basic Settings

Setting	Description
Device Name	Name shown in the Web UI and management platforms (1–64 characters).
Country/Region	Select the country/Region of deployment. Note: <i>Modifying the country/region may reset the bandwidth, channel, and transmit power. Paired devices must be in the same country/region to prevent disconnection.</i>
Time Zone	Choose the timezone for accurate logging and schedules.
NTP Server	Enter an NTP server (e.g., <code>pool.ntp.org</code>) to sync system time. Up to 4 NTP servers can be configured.
Role	Select the device role. Master transmits the bridge signal and typically connects to an uplink device such as a switch or router. Slave receives the bridge signal and extends the network to a remote site, typically connecting to terminal devices such as cameras. Note: <i>Switching roles clears the pairing information and requires re-pairing.</i>

Network Settings → Basic Settings

Manager Server Settings

Used to register the device with **GWN Manager** for centralized provisioning, firmware upgrades, and monitoring.

Basic Settings

Basic SettingsManager Server Settings

Manager Server

☒

*Manager Server Address ⓘ

*Manager Server Port

8443

8443 by default, valid range is 1-65535

Override Manager Server Address via DHCP Option 43 ⓘ

☒

Cancel

Save

Network Settings → Manager Server Settings

Setting	Description
Manager Server	Toggle to enable GWN Manager connectivity.
Manager Server Address	Input the IP or domain name of the GWN Manager server.
Manager Server Port	Default is <code>8443</code> . Valid range: <code>1–65535</code> .
Override via DHCP Option 43	When enabled, accepts a Manager address sent via DHCP.

See also: [GWN Manager Quick Installation Guide](#)

Security Management

This section controls remote access methods and session security for the GWN7302. It includes encrypted web access, SSH login options, and passwordless authentication for remote management via GDMS.

Web Service

Configure web UI access parameters:

- **Encrypted Server Port:** Defines the HTTPS port used to access the device's web interface. Default is **443**. Valid range is **1–65535**. Avoid reserved ports like **22** or **80**.

Note: The device can be managed via the [GWN App \(Single Device\)](#) function **only when this port is set to 443**.

- **Session Timeout (Mins):** Sets how long the web UI session remains active without user activity. The default is 5 minutes. Range: 1–1440. Changes to this setting take effect after the user logs out and logs in again.

Security Management

Web Service SSH Access Passwordless Remote Access

*Encrypted Server Port ⓘ 443 Default: 443. Range: 1-65535. Avoid using special ports(i.e. 22, 80).

*Session Timeout (Mins) ⓘ 1440 Default 5 range 1-1440

Cancel Save

Security Management → Web Service

SSH Access

Allow secure CLI-based configuration and remote diagnostics via SSH.

Security Management → SSH Access This section allows you to enable SSH functionality for device-level access using the command-line interface (CLI).

Note: SSH Access is intended for advanced users or support engineers. For security reasons, it's recommended to keep it disabled unless explicitly required.

Security Management

Web Service SSH Access Passwordless Remote Access

SSH Access ☒

Cancel Save

Security Management → SSH Access

Passwordless Remote Access

When enabled, users can log in remotely via **GDMS Networking** without entering a password. This improves convenience but should be used with caution in sensitive deployments.

Security Management

Web Service SSH Access **Passwordless Remote Access**

Passwordless Remote Access ☒ If enabled, account password will no longer be required when accessing remotely via GDMS Networking.

Security Management → Passwordless Remote Access

Upgrade

The **Upgrade** section provides administrators with two main methods to update the device firmware: **Manual Upgrade** and **Online Upgrade**. This functionality ensures that the GWN7302 stays up-to-date with the latest features, improvements, and security patches.

Manual Upgrade (Network Upgrade)

This method allows you to upload a local firmware `.bin` file directly from your computer.

- **System Firmware (.bin):** Click **Upload** to browse and select the firmware file. Use this method if you've downloaded the firmware package manually from the [official Grandstream site](#).
- **Network Upgrade:** Lets the device pull firmware from a user-specified server (HTTP, HTTPS, or TFTP).
- **Firmware Server Path:** Input the IP address or URL of the remote firmware server.

Upgrade

 **GWN7302**
Current Version : 1.0.2.22

Manual Upgrade

System Firmware (.bin)

Online Upgrade

Mode ☐ Official Online Upgrade ☒ Network Upgrade

Firmware Upgrade Method

Firmware Server Path

Allow DHCP Option 43 and 66 to Override Server ☒

Automatically Detect and Download Firmware at Bootup ☒

Upgrade

Online Upgrade (Official Online Upgrade)

This method allows the device to fetch and install firmware from a remote server or official source.

- **Mode: Official Online Upgrade:** automatically detects the latest firmware version when connected to the Internet.
- **Allow DHCP Option 43 and 66 to Override Server:**
Enable this option to allow DHCP to dynamically assign a firmware server.
- **Automatically Detect and Download Firmware at Bootup:**
When enabled, the device will auto-check, download, and install firmware during each reboot.

Alert:


Make sure the uploaded firmware is official and compatible with GWN7302. Do not power off the device during the upgrade.

User Management

The **User Management** section allows administrators to manage access credentials for the device. It includes two tabs:

Administrator

Used to modify the admin credentials for accessing the device interface.

The screenshot shows the 'User Management' interface with the 'Administrator' tab selected and highlighted by a red box. The 'Read-only User' tab is also visible. Below the tabs, there are three password fields: '*Current Password', '*New Password', and '*Confirm New Password'. To the right of the password fields, a note states: '8-32 characters, including at least 2 of the following: numbers, letters and special characters.' At the bottom of the form, there are 'Cancel' and 'Save' buttons.

User Management → Administrator

- **Current Password:** Enter the current admin password to authenticate the change.
- **New Password:** Set a new password for the admin account. It must be 8–32 characters long and include at least two of the following: letters, numbers, or special characters.
- **Confirm New Password:** Re-enter the new password to confirm.

Alert


Passwords must meet complexity requirements for security compliance.

Read-only User

Allows creation of a limited-access user who can view but not configure device settings.

- **Add Read-only User:** Toggle to enable or disable read-only account creation.
- **Read-only User Name:** The Default is `guest` (not editable).
- **Read-only User Password:** Set a password (8–32 characters) for the guest user.

Note: Read-only users can access the Web UI to monitor device status, but cannot access the mobile app or modify configurations.


The screenshot shows the 'User Management' interface with the 'Read-only User' tab selected and highlighted by a red box. The 'Administrator' tab is also visible. Below the tabs, there is a toggle switch for 'Add Read-only User' which is currently turned on. To the right of the toggle, a note states: 'Read-only users can log in to the web interface to view device information but cannot log in to the app.' Below this, there is a field for 'Read-only User Name' with the value 'guest'. At the bottom, there is a field for '*Read-only User Password' with a note '8-32 characters' to its right. At the bottom of the form, there are 'Cancel' and 'Save' buttons.

User Management → Read only User

Maintenance

Basic Maintenance

The **Maintenance** section provides essential tools for managing the device's operational state, diagnostics, backup/restore operations, and recovery procedures.



System Settings → Maintenance → Basic Maintenance

Backup

The **Backup** feature allows administrators to export the current device configuration to a local `.bin` file. This file can be saved and reused for future restoration or device duplication.

- Click **Export** to download the `.bin` file.
- The file is immediately saved to your computer; no additional confirmation is required.

Restore

The **Restore** option lets you import a previously saved `.bin` configuration file and apply it to the device.

- Click **Import** to browse and select the `.bin` file from your system.
- Upon confirmation, the device applies the configuration automatically.
- If the configuration becomes unusable, users can press and hold the **RST/PAIR** button on the device for 7 seconds to trigger a full factory reset.

Factory Reset Settings

Use this option to reset the device to its default factory configuration.

- Click **Factory Reset** to initiate the process.
- Alternatively, press and hold the physical RST/PAIR button for 7+ seconds.

Warning:

This will erase all current settings.

Reboot

Used to manually or automatically reboot the device.

- Click **Reboot Now** to restart the device immediately. Rebooting may interrupt any active sessions.
- **Timed Reboot** allows you to schedule automatic reboots at specific times:
 - Click **Edit** to set the time and select the days of the week.
 - Example: Schedule a reboot every **Saturday and Sunday at 12:46 PM** as shown.

System Settings → Maintenance

Note:

Management Wi-Fi

- o **Wi-Fi Name:** Displays the Wi-Fi name.
- o **Auto Turn Off Wi-Fi:** Toggles automatic shutdown after pairing.
- o **Wi-Fi Password:** Can be viewed/edited for secure access.

System Settings → Maintenance → Management Wi Fi

Alert:

Debug

System Settings → Maintenance → Debug

Used for troubleshooting by generating a debug file for support analysis.

- Click **Start Debugging** to initiate a session.
- Click **Stop Debugging** to end it manually.
- Sessions automatically stop after 30 minutes.
- Once generated, the debug file can be **downloaded** or **deleted** from the interface.

Ping/Traceroute

Use **Ping/Traceroute** to test network reachability and check the route path from the GWN7302 to another device or host.

Go to **System Settings** → **Maintenance** → **Ping/Traceroute**, then:

1. Select the **Diagnostic Tool**:
 - **Ping**: Tests whether the target IP address or hostname is reachable and displays packet loss and round-trip time.
 - **Traceroute**: Shows the route path used to reach the target host.
2. Select the **IP Protocol** (IPv4 or IPv6).
3. Enter the **Target IP Address / Hostname**.
4. Click **Start**.

The output appears in **Diagnosis Result**. For **Ping**, the result shows replies, packet loss, and round-trip time. For **Traceroute**, the result shows the route path to the target host.

Note: If you ping a **hostname** and it fails but an **IP address** works, that usually means **DNS** is not reachable or not configured.

The screenshot shows the 'Maintenance' section with the 'Ping/Traceroute' tab selected. The 'Diagnostic Tool' is set to 'Ping'. The 'IP Protocol' is set to 'IPv4'. The 'Target IP Address / Hostname' is '1.1.1.1'. A 'Start' button is visible. Below, the 'Diagnosis Result' section shows the output of the ping command:

```
PING 1.1.1.1 (1.1.1.1): 56 data bytes
64 bytes from 1.1.1.1: seq=0 ttl=52 time=24.318 ms
64 bytes from 1.1.1.1: seq=1 ttl=52 time=20.119 ms
64 bytes from 1.1.1.1: seq=2 ttl=52 time=19.796 ms
64 bytes from 1.1.1.1: seq=3 ttl=52 time=20.070 ms
64 bytes from 1.1.1.1: seq=4 ttl=52 time=19.882 ms

--- 1.1.1.1 ping statistics ---
5 packets transmitted, 5 packets received, 0% packet loss
round-trip min/avg/max = 19.796/20.837/24.318 ms
```


Maintenance → Ping

GDMS Networking / GWN Manager Connection Diagnostics

This section shows the current **connection platform** status (e.g., GDMS Networking) and the **connection status** (e.g., Registered or Unregistered).

Users can run a full cloud diagnostic process by clicking **Re-diagnosis**, which checks several phases, including DNS resolution, TCP/TLS connection, and cloud WS(S) upgrade. The log result is displayed below for real-time visibility.

You can also **Get Log** to view it live or **Export** it as a downloadable file for deeper analysis.



GDNMS Networking GWN Manager Connection Diagnostics

External Syslog


This section allows forwarding of system logs to a specified external syslog server.

Enter the IP address or URL of the server, select the log severity level (**Emergency, Alert, Critical, Error, Warning, Notice, Information, or Debug**), choose the desired protocol (UDP or TCP), then click **Save**.

External Syslog

Remote Support


When enabled, authorize Grandstream support engineers to temporarily access device diagnostic data, logs, and configuration information. This service is for troubleshooting and maintenance purposes only, and no personal information will be collected. All remote access sessions are fully encrypted, and this feature will be automatically disabled after 48 hours.



Remote Support


Steps to Enable Remote Support

1. Go to: **System Settings** → **Maintenance** → **Remote Support**.
2. Click on the blue **Remote Support** button to initiate the session.
3. A login window will appear, prompting for the login password. Input your admin credentials and click **OK** to continue.



Remote Support Login Password

4. Once validated, the system activates remote access. A confirmation message will appear below the button stating: "Remote support is active and will automatically stop in 48 hours."
5. At any time, you can manually terminate the session by clicking the **Stop Remote Support** button.



Stop Remote Support

Important Notes:

- Remote Support is temporary and automatically expires after 48 hours.
- It cannot be activated without entering the admin password.
- This feature is exclusive to support and troubleshooting scenarios and should be used cautiously to minimize security risks.

Alerts

This section displays device alerts and allows users to configure email-based notifications for various alert types.

Alerts Tab

The **Alerts** tab lists all current and past system alerts, such as signal loss or failed SSID connections. Each entry includes:

- **Content:** Description of the alert (e.g., SSID not detected).
- **Level:** Severity of the alert (e.g., *Urgent*).
- **Time:** Timestamp when the alert was triggered.
- **Action:** Trash icon to delete individual alerts.

Alerts					Alert Notification Settings
Email Notification					
Delete Delete ALL Read All					All Levels ▾
☒	Content	Level ▾	Time ▾	Action	
☒	Connect to device(ec:74:d7:...) ssid(Primary Device SSID) fail.	Urgent	2025/08/03 17:22:17		
☒	Connect to device(ec:74:d7:...) ssid(Primary Device SSID) fail.	Urgent	2025/08/02 17:22:17		
☒	Not detected the ssid(GWNA...) signal.	Urgent	2025/08/01 11:33:52		
Total 3					< 1 > 20 / page ▾

Alerts

Users can:

- **Delete** one or all alerts.
- **Mark all as read.**
- Filter alerts by severity using the **All Levels** dropdown.
- Access the alert settings by clicking **Alert Notification Settings** in the top-right corner.

Email Notification

Enable this feature to receive alerts via email.

Alerts

Alert Notification Settings

Alerts

Email Notification

Email Notification

Once enabled, the device will send related notification email to the receivers.

Sender

From Email Address

From Name

SMTP Settings

*SMTP Username

*SMTP Password

*SMTP Host

*SMTP Port

Skip Certificate Validation

Receiver

*Receiver Email Address

gs@grandstream.com

Add

Cancel

Save

Save and Test

Alerts → Email Notification

Email Notification toggle: Must be ON to activate alert emails.

Sender Configuration:

- **From Email Address** : Email address the alert will be sent from.
- **From Name** : Display name for the sender.

SMTP Settings:

- **SMTP Username** : Account used to authenticate the SMTP session.
- **SMTP Password** : Corresponding password for the SMTP account.
- **SMTP Host** : Outgoing mail server address (e.g., smtp.example.com).
- **SMTP Port** : Mail server port (default depends on encryption used).

Optionally, you can **Skip Certificate Validation** to send emails without SSL/TLS certificate checks.

Receiver(s):

- **Receiver Email Address** : One or more recipients (e.g., it@company.com). Multiple can be added.

Alert Notification Settings

Accessed from the top-right of either tab, this section lets users fine-tune what events trigger alerts and which ones should also be emailed, like Wi-Fi Disconnected, PoE Alarm, Device Upgrade Failed, etc.

Note: For the PoE Alarm, when the temperature reaches 110°C, the PoE output power will decrease. When the temperature reaches 115°C, the PoE OUT function will be disabled. When the temperature returns to 100°C, the PoE OUT function will be restored.

The interface is titled "Alerts > Alert Notification Settings". It contains a header with a tip: "Choose alert events. Web and app notifications are automatic; email alerts are optional." Below this, there are three sections: "Urgent Alert", "Severe Alert", and "Normal Alert". Each section lists events with checkboxes for enabling the alert and a toggle for email notifications. In the "Urgent Alert" section, "Wi-Fi Disconnected", "Memory Usage Threshold" (90%), "CPU Usage Threshold" (90%), "CPU Temperature Threshold" (110°C), "Device LAN Disconnected", and "Device has no Wi-Fi Signal" are all checked, with email toggles off. "PoE Alarm" and "Radar detection" are also checked, with email toggles on. The "Severe Alert" section has "Device Upgrade Failed", "Device Disconnected", and "Weak Wi-Fi Signal" unchecked, with email toggles off. The "Normal Alert" section has "Device Upgraded Successfully", "Device Connected", "Device Password Updated", and "Normal Wi-Fi Signal" unchecked, with email toggles off. At the bottom are "Cancel" and "Save" buttons.

Alerts → Alert Notification Settings

Alert Levels:

- **Urgent Alerts:** Critical conditions like Wi-Fi or LAN disconnects, or high CPU/memory/temperature thresholds.
- **Severe Alerts:** Upgrade failures or device disconnections.
- **Normal Alerts:** Device upgrades, connections, and password changes.

Each event can be toggled ON/OFF for web visibility, and optionally enable the **Email** toggle for remote notifications.

Operation Log

The **Operation Log** page records system and user actions performed on the device, such as login attempts, configuration changes, pairing actions, link tests, and spectrum analyzer operations.

Navigate to **Web UI** → **System Settings** → **Operation Log**.

The "Operation Log" interface includes an "Export" button and a table of events. A detailed view of a "Sign In" event is shown, displaying user information and the result. A calendar widget is also present for filtering events by date.

Time	Address	Operation
2026-06-02 08:32:09	192.168.5.1	{ "userName": "admin", "userPwd": "32be5f6e1b18ee79c48ce3a6e43116f6b23028253c324f06352cc7d8b75247fe", "userFrom": "web" }
2026-06-02 08:28:56	192.168.5.1	
2026-06-02 08:27:46	192.168.5.1	
2026-06-02 08:18:49	192.168.5.1	
2026-06-02 08:13:23	192.168.5.1	
2026-06-01 15:18:37	192.168.5.247	Login success
2026-06-01 15:18:33	192.168.5.247	Login failed
2026-06-01 15:11:27	192.168.5.247	Update config(success): set security
2026-06-01 15:11:17	192.168.5.247	Login success
2026-06-01 14:56:26	192.168.5.247	Login success
2026-06-01 13:58:37	192.168.5.247	spectrum analyzer
2026-06-01 13:58:01	192.168.5.247	Login success
2026-06-01 13:45:10	192.168.5.247	Add config(success): pairing device
2026-06-01 13:39:36	192.168.5.247	Login success
2026-06-01 13:39:33	192.168.5.247	Login failed
2026-06-01 13:25:54	192.168.5.247	Add config(success): pairing device
2026-06-01 13:24:05	192.168.5.247	Add config(success): pairing device

The operation log table displays each record with the following information:

Field	Description
Time	Displays the date and time when the operation occurred.
Address	Displays the IP address of the client or device that performed the operation.
Detail	Displays a summary of the recorded operation, such as login success, login failed, link test, spectrum analyzer, or configuration update.

Use the **date filter** to display logs within a selected time range. The available quick filters include **All Time**, **Today**, **This Week**, and **This Month**.

Use the **Detail** search box to search for specific operation records.

Click the information icon next to a log detail to view more information about that operation, including the page name, operation type, operation content, and result.

Click **Export** to download the operation log as a CSV file.


Tools

Link Test

The Link Test measures throughput between the two devices.


Who Does What?

- **Either device can be Server or Client**, but **recommended**:
 - **Master (Site A) → Server** (easier to leave running).
 - **Slave (Site B) → Client** (initiates the test).



Link Test Tool page


Note: Running the link test will temporarily affect the wireless transmission rate. A confirmation message will appear before proceeding.



Link Test Tool page

On Master (Server):

- Go to **Web UI** → **Tools** → **Link Test**.
- Select **iPerf Type = Server** and click **Start**.
- Leave it running (listening).



Link Test Tool Server side

Important Notes:

- In Server Mode, the device will stop automatically after 1 hour if no Client connects.
- Stay on the Link Test page during the test; leaving aborts the session.

On Slave (Client):

- Go to **Web UI** → **Tools** → **Link Test**.
- Select **iPerf Type = Client**.
- Enter the **Server's IP address** (auto-filled in most cases).
- (Optional) Enable **Bidirectional iPerf** to test both directions.
- Click **Start** to begin.

Tools

[Link Test](#) Antenna Alignment Spectrum Analyzer

First, set the Iperf type to Client or Server, then click "Start" to begin the link test. In Server mode, please complete the test within 1 hour; otherwise, it will stop automatically.

Iperf Type:

Bidirectional Iperf: ☒ If turned off, only the transfer speed from the Iperf client to the Iperf server will be tested.

*Server Address:

*Thread: Range 1-128

*Test Time(s): Range 1-300

*Test Interval(s): Range 1-59

Link Test Tool Client side

Review Results:

- Throughput and stability will appear under **Test Result**.
- Stop manually when finished.

Tools

[Link Test](#) Antenna Alignment Spectrum Analyzer

*Test Interval(s): Range 1-59

Please stay on this page, otherwise the link test will be aborted.

Test Result

[18][RX-C]	27.00-28.00	sec	10.9 MBytes	91.0 Mbits/sec		
[20][RX-C]	27.00-28.00	sec	10.9 MBytes	91.0 Mbits/sec		
[22][RX-C]	27.00-28.00	sec	10.9 MBytes	91.0 Mbits/sec		
[24][RX-C]	27.00-28.00	sec	10.9 MBytes	91.0 Mbits/sec		
[SUM][RX-C]	27.00-28.00	sec	54.4 MBytes	455 Mbits/sec		
[5][TX-C]	28.00-29.01	sec	10.7 MBytes	89.3 Mbits/sec	0	216 KBytes
[8][TX-C]	28.00-29.01	sec	10.6 MBytes	88.4 Mbits/sec	0	240 KBytes
[10][TX-C]	28.00-29.01	sec	9.34 MBytes	77.7 Mbits/sec	0	567 KBytes
[12][TX-C]	28.00-29.01	sec	9.88 MBytes	82.2 Mbits/sec	0	669 KBytes
[14][TX-C]	28.00-29.01	sec	10.4 MBytes	86.5 Mbits/sec	0	240 KBytes
[SUM][TX-C]	28.00-29.01	sec	51.0 MBytes	424 Mbits/sec	0	
[16][RX-C]	28.00-29.01	sec	11.4 MBytes	94.8 Mbits/sec		
[18][RX-C]	28.00-29.01	sec	12.1 MBytes	101 Mbits/sec		
[20][RX-C]	28.00-29.01	sec	12.1 MBytes	101 Mbits/sec		
[22][RX-C]	28.00-29.01	sec	12.1 MBytes	101 Mbits/sec		
[24][RX-C]	28.00-29.01	sec	11.9 MBytes	98.8 Mbits/sec		
[SUM][RX-C]	28.00-29.01	sec	59.6 MBytes	496 Mbits/sec		


Review Results

Antenna Alignment

The user can fine-tune the link quality using either method:

a) Using Web UI – Antenna Alignment Tool


- Go to **Web UI** → **Tools** → **Antenna Alignment**.
- Select the paired device from the list.
- Click **Start** to monitor real-time signal strength.
- Adjust the antenna angle until the graph shows the strongest (highest) dBm value.



Antenna Alignment Tool

b) Using Device LEDs

- Check the **3 Signal LEDs** on the side of the unit.
- Rotate or tilt the device slowly until you reach **3 solid green bars** for optimal signal.



Device Signal LEDs

For complete pairing and alignment instructions, refer to the [GWN7302 Pairing Guide](#).

Spectrum Analyzer

The Spectrum Analyzer runs a single scan of nearby 5 GHz channels to help you pick a cleaner channel (less interference).

How it works: Click **Start** to run **one** spectrum analysis.
To scan again, click again

How to read the results:


- **Signal Strength (green bars):** lower (closer to **-85 dBm**) is better (less interference).
- **Channel Load (orange bars):** lower is better, ideally **below 10%**.
- **SSID Quantity:** Fewer SSIDs usually mean a cleaner channel.
- Hover a bar to see channel details (timestamp, signal strength, channel load, SSID quantity).

Steps:

1. Go to **Web UI** → **Tools** → **Spectrum Analyzer**.

2. Click **Start** to run a **single** scan.
3. Review the chart and pick a channel with **low load** and **better signal conditions**.
4. If you change settings and want fresh results, click **Start** again.

Tip: Ideal conditions are **Signal Strength below -85 dBm** and **Channel Load below 10%** (these thresholds are shown on the chart).



Spectrum Analyzer Tool

Change Log

This section documents significant changes from previous versions of the GWN73xx user manuals. Only major new features or major document updates are listed here. Minor updates for corrections or editing are not documented here.

Firmware Version 1.0.5.4

- Added online and offline status indicators for paired slave devices in the topology diagram. [\[Overview\]](#)
- Added Historical Monitoring charts for throughput, negotiated rate, and signal strength. [\[Overview\]](#)
- Optimized device pairing guidance with wired pairing, device takeover, and a link to the dedicated Pairing Guide. [\[Device Pairing\]](#)
- Added STP option. [\[Network Settings\]](#)
- Added Operation Log page for viewing, filtering, and exporting device operation records. [\[Operation Log\]](#)
- Added Traceroute support to the Ping diagnostic tool for route tracking. [\[Ping/Traceroute\]](#)
- Updated the Maintenance page tab layout. [\[Maintenance\]](#)
- Added support for configuring up to 4 NTP servers. [\[Basic Settings\]](#)
- Added RF Settings note reminding users to keep the SSID, password, and encryption method consistent across paired devices. [\[RF Settings\]](#)

Firmware Version 1.0.3.28

- No major changes.

Firmware Version 1.0.3.22

- No major changes.

Firmware Version 1.0.3.17

- This is the initial release.